

SINGER
195K

NUMERICAL LIST OF PARTS FOR 195K MACHINES

PART No.	DESCRIPTION	PART No.	DESCRIPTION	PART No.	DESCRIPTION	PART No.	DESCRIPTION
76	Knee Lifter Lifting Lever Connecting Rod Joint Hinge Screw	802	Knee Lifter Lifting Lever Hinge Screw	5601	Knee Lifter Bell Crank Hinge Pin	52097	Feed Lifting Rock Shaft Screw Centre
144	Arm Shaft (horizontal) Screw	857	Needle Set Screw	5735	Knee Lifter Bell Crank Spring	52097	Feed Rock Shaft Screw Centre Tension Stud
145	Rotating Hook Shaft Bevel Gear Case (lower) Screw	966	Feed Lifting Rock Shaft Connecting Rod Cap Screw	8879	Arm Spool Pin Washer (cloth)	52098	Thread Take-up Lever Thread Eyelet Bushing
157	Feed Lifting Rock Shaft Crank Clamping Screw	1036	Thread Take-up Crank Set Screw	11170	Presser Bar Spring Washer	52130	Needle Bar (hollow)
157	Feed Rock Shaft Crank Clamping Screw	1037	Thread Take-up Crank Position Screw	12240	Knee Lifter Lifting Lever Pin	52155	Feed Connecting Link
176	Presser Foot Screw	1053	Rotating Hook Thread Guard Screw	12241	Knee Lifter Lifting Lever Link	52165	Needle Bar Bushing (lower) Thread Eyelet
176	Face Plate Screw (lower)	1065	Needle Bar Crank Position Screw	12327	Presser Bar Lifting and Releasing Lever Bracket	52171	Arm Oil Tube
178	Knee Lifter Bell Crank Bracket Screw	1133	Needle Bar Bushing (lower) Set Screw	12329	Tension Releasing Lever Spring	52182	Arm Oil Tube
219	Arm Side Shield Screw	1133	Needle Bar Bushing (upper) Set Screw	12391	Presser Bar (hollow)	52183	Arm Oil Tube Packing (wick)
223	Slack Thread Regulator Set Screw	1133	Presser Bar Bushing (lower) Set Screw	12398	Tension Releasing Lever Hinge Pin	52184	Arm Shaft (horizontal) Bushing (intermediate) Oil Tube Packing (wick)
226	Face Plate Thread Guard (lower) Screw	1148	Rotating Hook Shaft Bushing (back) Set Screw	12416	Knee Lifter Lifting Lever Connecting Rod Joint	52184	Arm Shaft (horizontal) Flanged Bushing (front) Oil Tube Packing (wick)
226	Face Plate Thread Guard (upper) Screw	1148	Rotating Hook Shaft Bushing (front) Set Screw	12431	Bed Slide	52184	Arm Top Cover Oil Tube (bent) Packing (wick)
313	Feed Bar Screw Centre	1148	Rotating Hook Shaft Bushing (front) Set Screw	12432	Bed Slide, complete	52184	Arm Top Cover Oil Tube (long) Packing (wick)
335	Thread Take-up Lever Guard Screw	1253	Rotating Hook Set Screw	16510	Knee Lifter Lifting Lever	52184	Arm Top Cover Oil Tube (short) Packing (wick)
375	Feed Connecting Link Hinge Screw	1259	Arm Shaft (horizontal) Bevel Gear Set Screw	24041	Needle Bar Connecting Stud	52184	Arm Oil Tube (short)
375	Feed Forked Connection Hinge Screw	1259	Arm Shaft (horizontal) Collar Set Screw	29633	Feed Rock Shaft Crank	52185	Arm Shaft (horizontal) Bushing (intermediate) Oil Pad (braided cotton)
375	Feed Lifting Rock Shaft Connecting Rod Hinge Screw	1259	Arm Shaft (upright) Bevel Gear (lower) Set Screw	32574	Tension Releasing Pin	52193	Arm Shaft (horizontal) Flanged Bushing (back) Oil Pad (braided cotton)
435	Arm Shaft (horizontal) Bushing (intermediate) Set Screw	1259	Arm Shaft (upright) Bevel Gear (upper) Set Screw	40264	Rotating Hook Bobbin	52193	Arm Shaft (horizontal) Flanged Bushing (front) Oil Pad (braided cotton)
435	Machine Pulley Set Screw	1259	Rotating Hook Shaft Bevel Gear Set Screw	40392	Rotating Hook Bobbin Case Latch	52194	Arm Shaft (horizontal) Flanged Bushing (back) Oil Pad (felt)
435	Thread Take-up Lever Hinge Pin Set Screw	1367	Rotating Hook Section Screw	40393	Rotating Hook Bobbin Case Hinge, complete	52194	Arm Shaft (horizontal) Flanged Bushing (front) Oil Pad (felt)
443	Arm Shaft (horizontal) Flanged Bushing (back) Set Screw	1380	Rotating Hook Bobbin Case Tension Spring Screw	40394	Rotating Hook Bobbin Case Tension Spring	52207	Needle Bar Connecting Link Lubricating Pad (wood)
443	Arm Shaft (horizontal) Flanged Bushing (front) Set Screw	1513	Feed Lifting Rock Shaft Screw Centre Nut	42367	Arm Oil Tube Packing (braided cotton)	52216	Thread Take-up Crank
448	Feed and Feed Lifting Eccentric Set Screw	1513	Feed Rock Shaft Screw Centre Nut	43944	Tension Releasing Lever	52235	Rotating Hook Bobbin Case
448	Thread Take-up Spring Regulator Set Screw	1518	Feed Connecting Link Hinge Screw Nut	49010	Arm Shaft (horizontal) Collar	52237	Rotating Hook Bobbin Case, complete
448	Knee Lifter Lifting Lever Pin Set Screw	1518	Feed Forked Connection Hinge Screw Nut	50053	Arm Side Cover Thumb Screw	52239	Arm Spool Pin and Thread Eyelet
453	Presser Bar Guide Bracket Set Screw	1518	Feed Lifting Rock Shaft Connecting Rod Hinge Screw Nut	50117	Feed Dog Screw	52239	Arm Top Cover Spool Pin and Thread Eyelet
591	Rotating Hook Bobbin Case Tension Regulating Screw	1519	Feed Bar Screw Centre Nut	50150	Rotating Hook Shaft Collar Screw	52262	Arm Shaft (horizontal) Bushing (intermediate)
592	Rotating Hook Bobbin Case Latch Stop Screw	1520	Presser Bar Lifter Screw Nut	50191	Feed Lifting Rock Shaft Screw Centre	52263	Arm Shaft (horizontal) Bushing (intermediate) Oil Pad (felt)
624	Thread Retainer Set Screw	1521	Knee Lifter Lifting Lever Connecting Rod Lock Nut	50191	Feed Rock Shaft Screw Centre	52265	Feed Lifting Rock Shaft Crank
688	Pressure Regulating Thumb Screw	1560	Tension Regulating Thumb Nut	50305	Tension Stud Set Screw	52267	Feed Lifting Rock Shaft Crank Slide Block
689	Presser Bar Lifter Screw	2102	Tension Disc	50608	Arm Pin Plug Screw (back)	52268	Needle Bar Bushing (lower)
691	Throat Plate Screw	2974	Rotating Hook Bobbin Case Latch Lever Fulcrum Pin	50668	Arm Shaft (horizontal) Bevel Gear Case (upper) Screw (long)	52279	Arm Shaft (upright) Bushing (upper) Oil Wick (braided cotton)
704	Rotating Hook Bobbin Case Holder Position Bracket Screw	2975	Rotating Hook Bobbin Case Latch Spring	51369	Arm Top Cover Screw		
725	Bed Slide Spring Screw	4307	Bed Slide Spring	52014	Needle Bar Bushing (upper)		
768	Knee Lifter Lifting Lever Link Hinge Screw	5596	Knee Lifter Bell Crank	52016	Presser Bar Lifter		
775	Needle Bar Connecting Link Cap Screw	5599	Knee Lifter Bell Crank Bracket	52018	Rotating Hook Bobbin Case Holder Position Bracket		
				52022	Thread Take-up Lever		
				52024	Thread Take-up Lever Link		
				52027	Thread Guard (side of arm)		
				52028	Knee Lifter Lifting Lever Connecting Rod		
				52031	Feed Dog		
				52033	Throat Plate (small needle hole)		
				52053	Face Plate Thread Guard (lower)		
				52073	Feed Connecting Link Hinge Stud		