


**SINGER**  
**121C200A,C300A**  
**Supplemental**

# SIN 121C200A Supplemen

The parts illustrated and part numbers  
Models 121C200A & Models 121C300  
on Form 21627 (Rev. 677).



# CENTURION

Handwritten notes: 502506, 500414

# SINGER & 121C300A Parts List

This chart indicates the difference between  
Models 121D200A & 121D300A as shown

